

ISO Bur Head Size Guide

/010 = 1.0mm ●

/012 = 1.2mm ●

/014 = 1.4mm ●

/016 = 1.6mm ●

/018 = 1.8mm ●

/019 = 1.9mm ●

/022 = 2.2mm ●

/026 = 2.6mm ●

/028 = 2.8mm ●

/030 = 3.0mm ●

/035 = 3.5mm ●

/040 = 4.0mm ●

/043 = 4.3mm ●

/045 = 4.5mm ●